



MIRROR FINISH IN 2 STEPS STARTING FROM A 2B FINISH

PREFINISHING:



- P/N 42245 – 10 PACK TRIZACT A45 - 400 GRIT
- P/N 42230 – 10 PACK TRIZACT A30 - 600 GRIT
- P/N 42216 – 10 PACK TRIZACT A16 - 1200 GRIT
- P/N 42206 – 10 PACK TRIZACT A06 - 2000 GRIT

POLISHING:



- P/N 42013N – 4 PACK SUPERPOLISH SLEEVES

**Use A Different Superpolish Sleeve For Each Color Polishing Compound*



- P/N 40013 – WHITE POLISHING PASTE (1200-1500 GRIT)
- P/N 40014 – BLUE POLISHING PASTE (2000 Grit)



- P/N CS2410 – COTTON BUFFING WHEEL

**For Use With Pink Polishing Paste*

OR



- P/N 40019M – 8 PACK COTTON RINGS

**For Use With Pink Polishing Paste*



POLISHING (Cont.):



- P/N 40015T – 2oz. TUBE PINK POLISHING CREAM
- P/N 40015 – 2.2lb. CAN PINK POLISHING CREAM



- P/N 40029 – 7oz. SCATTER CONTAINER WITH BRIGHTEX
- P/N 40028 – 2.2lb. BAG BRIGHTEX



- P/N 40031 -MICROFIBER CLOTHS

**For Use With Brightex for removal of cream and compound residues*

RECOMMENDED TOOLS & ACCESSORIES:



PTX ECO SMART
(P/N PTX ECO SMART)



EXPANSION ROLLER
(P/N 47005)