

Hydraulic Driving Machine

Model 3 6243 0010



Illustration can differ from the original.

Schematics

Spare Parts List					
Description:			Part and drawing number:		
Hydraulic Driving Machine			3 6243 0010		
Item	Qty.	Description	Part and drawing no.		Remarks
10	1	Connection plate	5 1220 3070		
11	2	Connection nipple	5 1220 3100		
12	2	O-Ring	9 1901 3410	*	
13	2	O-Ring	9 1901 2140	*	
14	3	Socket head screw	9 1112 5130		
20	1	Gearbox housing I	3 6242 4020		
22	1	Pinion	3 6242 4510		
23	1	Feather key	9 1501 3110		
26	1	Intermediate housing	3 6242 4510		
27	5	Fillister-head screw	9 1110 4020		
28	1	Hydraulic motor, Assy.	9 5501 0170	*	Only sealing set 2 2406 9000
30	1	Adjusting washer	9 3331 0530		
30	1	Adjusting washer	9 3331 0540		
30	1	Adjusting washer	9 3331 0550		
30	2	Adjusting washer	9 3331 0590		
31	1	Coupling	3 6339 4110		
40	1	Gearbox housing II	3 6339 4220		
41	1	Axial grooved ball bearing	9 1021 0020	*	
42	1	Compensating ring	9 3326 1220	*	
43	1	Grooved ball bearing	9 1003 0020	*	
44	2	Needle sleeve	9 1014 0200	*	
46	1	Worm wheel	3 6339 4130	*	
47	1	Worm	3 6339 4120	*	
48	1	Grooved ball bearing	9 1003 0020	*	
49	1	Locking ring	3 6339 4190		
50	1	Bearing cover	3 6339 4160		
80	1	Exhaust square	6 1015 7030		
81	2	Snap ring	9 1702 0320		
	1	Twist valve	5 1220 3800		see extra list
	2	Screw-in screwing	9 2124 0240		
	1	Quick-seal coupling set	2 1317 9010		


Spare Parts List

Description:


Hydraulic Driving Machine

Part and drawing number:

3 6243 0010



Spare Parts List					
Description:				Part and drawing number:	
Twist Valve				5 1220 3800	
Item	Qty.	Description	Part and drawing no.		Remarks
301	1	Valve housing Assy.	5 1220 3910		
302	1	Twist sleeve	5 1220 3020		
303	1	Pressure rod	5 1220 3060		
304	1	Lens screw	9 1166 0170		
305	1	Snap ring	9 1702 0020		
306	1	Gate	5 1220 3050		
307	1	Snap ring	9 1703 0260		
308	1	Socket head screw	9 1110 2090		
309	1	Disc	9 3302 0150		
310	1	Adjusting slide	2 1317 3320		
311	1	Spring plate	2 1317 3070		
312	1	Slide	2 1317 3110		
313	1	Lock washer	9 1706 0140		
314	1	Sleeve	2 1317 3090		
315	1	Guide	2 1317 3100		
316	1	Pressure spring	9 1803 0660		
317	1	Pressure spring	9 1803 1700		
318	1	Lock washer	9 1706 0180		
319	1	O-Ring	9 1901 3290	*	
320	1	O-Ring	9 1901 9800	*	
321	1	O-Ring	9 1901 2550	*	
323	1	O-Ring	9 1901 6020	*	
326	1	O-Ring	9 1901 2080	*	
327	1	Pressure spring	9 1803 4070		
331	2	Locking screw	9 1174 0010		
333	2	Adjusting washer	9 3331 0130		
333	2	Adjusting washer	9 3331 2010		
337	1	Adjusting washer	9 3331 0170		
390	1	Safety valve	5 1220 3300		see extra list

Spare Parts List					
Description: Twist Valve			Part and drawing number: 5 1220 3800		
					

[illegible]

Spare Parts List					
Description:			Part and drawing number:		
			5 1220 3300		
Safety Valve					
